

User Guide:

Adjustable Nozzle Valve

Power Button



To turn on the sprayer:

- 1) Plug device into power outlet
- 2) Turn on the red switch button (Power Button)
- 3) Turn on the blue nozzle adjustment valve to a desired flow rate (Adjustable Nozzle Valve)

To turn off the sprayer:

- 1) Turn the blue adjustable nozzle valve to off position
- 2) Turn off the red switch button (Power Button)
- 3) Unplug the device from the outlet